

Home Model 600X

A PRODUCT of: Joyful Earth Technologies www.JoyfulEarthTech.com



What you now possess is technology that is so advanced that Earth science will require decades to catch up.

The Home Model optically paints away the confusion from this invasive electrical input, leaving you feeling like you're living in the pristine, pre-technological, primordial world. Free from this onslaught, the body can finally heal and the mind can emerge from the fog caused by this electromagnetic confusion.

Food and water exposed to the Home Model regain their original intent: to hydrate, fuel, and nourish the body, and to transmit the information patterns of abundant, healthy life.

Basic Usage (Quick Guide)

The Home Model is designed to be placed on a shelf and forgotten. It can be left there to collect dust, or it can be moved from room to room on a daily or weekly schedule.

The Home Model has two modes: **Clear** and **Bask**. Clear repairs the damage done to the energy body by Microwave Energy and by Low Frequency EMFs (i.e. "radionics"). Bask restores the energy lost due to this damage, leaving you, your loved ones, and anyone else in the vicinity, free to live the life you/they were meant to live.

When the switch is set to **Clear**, it actually does both a *Clearing* cycle and a *Bask* cycle. If you just want to "bask" in the energizing effects of this restorative cycle, then set the switch to **Bask**. But, it would be wise to flip this switch back to the **Clear** setting once you're done (i.e. run the Tranzzporter on the **Clear** setting most of the time—and especially after to move it to a new location).

To use the Tranzzporter™:

1. Be sure to read the **Caution** and **Warning** at the end of this document.
2. Set the switch to **Clear** (or **Bask** if the restorative effect is all you desire, though if this is your first usage, then I urge you to set it to **Clear**).
3. Plug it in, using either the battery cable with a 9 Volt battery attached (see **Battery Power** below), or use the enclosed transformer—whichever is most convenient.

Instructions for Home Model 600X

If using the **battery cable**, simply snap a standard 9 volt battery onto one end of the cable, and then plug the other end into the Home Model. Since there's only one possible place to insert it, have no worries about plugging it into the wrong place. Keep the battery at least 2 feet away from the Tranzzporter (otherwise it will interfere with the Clearing effect).

The **Transformer** connects to the same place as the battery cable, so if using the transformer, connect it to the Home Model and then plug the other end into a **120VAC** outlet.

For use outside of the USA, you will likely need an adapter (to allow insertion into a different kind of wall jack). You also may need a voltage converter. **ONLY PLUG THE TRANSFORMER INTO A SOURCE THAT SUPPLIES 110 TO 120 VAC 60Hz** (the standard for USA). If you wish to use the enclosed transformer in a country that only provides **240VAC** (or any other voltage that is not **120VAC**), then you must use a **voltage converter**.

4. There will be a five second delay before the Home Model begins a session. During this time, the red light will flash once a second. This is to indicate that a session is about to happen and it would be a good idea to move your eyes at least 3 feet away from the lights (see **Cautions** below).
5. To stop the Home Model mid-session, simply push the **Start/Stop** button. To start a new session, press the **Start/Stop** button.
6. When the Home Model finishes a cycle, it goes to sleep (unless it's in one of the Continuous modes [see **Continuous Mode** below]). It will awake at some random time, 1 to 2 hours later and run another session and then go back to sleep and then come back on at a random time and run another session, etc., etc.
7. The best place to put the Home Model is anywhere where it won't shine directly in peoples eyes. You can place it there and let it collect dust, or you can move it around. Moving it around is a good way to insure that it gets everything in your house (or wherever you plan to use it), especially if there's more than one room you wish to protect, as it will only protect one room at a time. Also, use it to clear out hotel/motel rooms for a more peaceful experience away from home. The possibilities are endless. Before using it in a car, read the **Warning**, below.

Details

This model is designed to be placed high on a shelf or corner table or somewhere in the room where the bright lights won't shine in any ones eyes. In the default mode (the mode it's in when first powered up), it will periodically come on and clear the room of "dense energies". This model will, also, repair EMF damage in the human energy body¹ of anyone within eye

¹ Also known as the "chakra system".

Instructions for Home Model 600X

shot of the unit. See [Cautions](#) and [Warning](#) below.

When you first plug in the Home Model, there will be a five second delay before the lights begin to glow. This is to allow you to move your eyes away from the unit before it comes on. The lights are bright and it's just not a good idea to let bright lights shine into your eyes—especially Ultra-Violet light (UV or “black” light). The red light will flash once per second to give you visual indication that it's time to move your eyes away.

After the 5 second delay, the Home Model will transition through it's colors (do a “session”) and then go to sleep for a random period of time.

For more information, go to the www.JoyfulEarthTech.com website.

Battery Power

The Home Model can be powered by a battery. The battery must be kept at least 2 feet away from the box. This is why the battery is not inside the box and why a battery cable comes with the unit. One side of the battery cable connects to the Power Jack on the unit (there's only one place to insert the plug, so have no worries about inserting it in the wrong place), and the other end snaps on to a standard 9 volt battery (type PP3)². This can be a Zinc-Carbon battery, an Alkaline battery (such as a Duracell or Energizer), or a rechargeable battery. As long as the battery is between 6 and 12 volts, will snap onto the clip and has the proper polarity, it will work.

Polarity Reversal: If the polarity is wrong, it won't hurt the Home Model (as long as the reverse voltage is 12 volts or less). The Home Model is designed to withstand a reversal of polarity. It won't run, but it also won't be damaged. It will, however, drain the battery, so as soon as it's clear that the battery is not powering the device, remove it and try something different.

Lithium Battery (LiMnO₂): A Lithium battery (such as the **Duracell ultra Lithium**) will last around twice as long as an Alkaline battery, but an Alkaline battery is cheaper, so it's a toss-up as to which is better.

Lithium Polymer (Li-Polymer): Probably the best system is two or three Li-Polymer rechargeable batteries and a charger (make sure it's designed to charge Li-Polymer batteries. No other battery charger will do). Also, be sure not to allow the battery to run all the way down. This can ruin the battery. That's why it's good to have at least two batteries—that way, you can swap them out once every week or two. In other words, have one on the charger while the other one is in service. In the long run, this is the cheapest and most environmentally friendly way to go.

There are online battery distributors, such as BatteryJunction.com, and BatteryMart.com that sell batteries for substantially less (as much as half price or more) than you will pay at the

2 Just a plain old 9v “transistor” battery that you can get at any drug store, supermarket, etc, like a Duracell or Energizer.

Instructions for Home Model 600X

supermarket.

It's time to change the battery when any of the colored lights, or the red light, begin to flash erratically or if it otherwise behaves abnormally.

In The Car

First, read the **Warning** (below). Driving through town and especially on many highways, puts you at the greatest risk of exposure to microwave radiation. Just consider how many cell towers you pass on a typical automobile journey—they're everywhere! Place the Home Model on the backseat, so the lights don't interfere with your driving (esp. at night).

Here are two ways you can run the Home Model in the car:

1. Use the battery cable along with a 9V battery (see **Battery Power**, above). Make sure to keep the battery at least 2 feet away from the box.
2. You can also get a car cigarette lighter power cable that can be used with the Home Model at the following places:
 - <http://www.calradstore.com/90-618.html>
 - <http://www.camera2000.com/en/car-vehicle-charger-dc-12v-5-5mm-2-1mm-cigar-lighter-power-adapter.html>
 - <http://www.securitycamera2000.com/products/Car-Vehicle-Charger-DC-12V-5.5mm-%7B47%7D-2.1mm,-Cigar-Lighter-Power-Adapter.html>
 - http://www.costcaptain.com/mm5/merchant.mvc?Screen=PROD&Store_Code=C&Product_Code=TDX_90945Y

Function Switch

The **Function Switch** has two settings:

- I. **Clear:** does one *Clearing* cycle and one *Bask* cycle. This is the most effective way to clear a persons energetic field (chakras) and to clear a room. Use this setting when running the Home Model for the first time and also, whenever you move the Home Model to a new area—even if that area has been done before. Each time you move the Home Model, run a Clear cycle. The rule-of-thumb is to keep the Home Model on Clear all the time, unless there are times when you desire more of the restorative provided by the Bask cycle (see **Bask**, below).

When the Clearing cycle is running, the red Clearing Indicator Light will glow. This is to indicate that the *Clearing* feature is active. This only occurs during the *clearing* portion of the Clear function (i.e. not during the *bask* cycle portion of the Clear

Instructions for Home Model 600X

function).

- II. **Bask:** Only does a *bask* cycle. This is the same Bask function that is run when the switch is set to Clear. The only difference is that when the switch is set to Bask, only the *bask* function is run. Use this setting if all you want to do is bask in its harmonizing, restorative influence.

Now, I realize that using a similar term for both the Clear *function* and the clearing *action* is confusing. Perhaps a little history will help. Originally, there was only one mode: *Clearing*. But, then we discovered the restorative mode (later called Bask) and figured out that a restorative cycle should always follow a clearing cycle. It's still called "Clear" but now it includes the restorative cycle as well. After that, we found that we occasionally liked running just the restorative. We liked to *bask* in it, so that's what we called it. We added a switch to make it possible to do this. When set to **Clear**, it runs a *bask* as well—because a *bask* should always follow a *clearing*. But, when set to **Bask**, it only runs *bask*.

Flipping the **Function Switch** when the Home Model is in Continuous Mode will cancel Continuous Mode (see [Continuous Mode](#) below).

Start/Stop Button

After the Home Model runs a session, it goes to sleep (a low power mode designed to save battery power). The duration of this sleep is random (approximately 1 to 2 hours). If you want to start a new session before that time, press the **Start/Stop** button. If you want to stop a session, press the **Start/Stop** button.

The same 5 second delay that occurs after the unit is first powered up, also follows a press of the **Start/Stop** button. This is to give you a chance to move your eyes away from the lights (they're very bright).

Continuous Mode

By holding the **Start/Stop** button down for **5 flashes** of the red light (as you hold the button down, the red light will flash once a second) the Home Model runs in **Continuous Mode**. In this mode the pause between sessions is around 5 seconds, or nearly continuous. The behavior is slightly different depending on the setting of the Function Switch. If the Function switch is set to Clear, then Clear sessions (which include a *clearing* and a *bask*) are run over and over with only a 5 second pause in between. If the Function Switch is set to Bask, then it will only run Bask sessions (again, with a 5 second pause in between).

Running the Home Model in Continuous Mode with the battery, will run the battery down substantially faster. To prevent this, run the Home Model with the Transformer instead (the Transformer is that little, black, kinda heavy, cube shaped thing that plugs into the wall).

To cancel **Continuous Mode** (i.e. restore the Tranzzporter™ to default functioning) simply press the **Start/Stop** button or disconnect the battery for 20 seconds and then reconnect it,

Instructions for Home Model 600X

or change the position of the **Function Switch**.

Continuous Dazzle Mode

By setting the **Function Switch** to **Clear** and then holding the **Start/Stop** button down for 10 **flashes** of the red light (as you hold the button down, the red light will flash once a second) the Home Model will run in the **Continuous Dazzle Mode**. In this mode the Dazzle pattern is always run when the Home Model is *clearing*. This only applies if the **Function Switch** is set to **Clear**. Otherwise, if set to **Bask**, the Home Model will behave the same as in [Continuous Mode](#).

Running the Home Model in Continuous Dazzle Mode with the battery, will run the battery down substantially faster. To prevent this, run the Home Model with the Transformer, instead (the Transformer is that little, black, kinda heavy, cube shaped thing that plugs into the wall—also know as a “battery eliminator”, or wall-wart).

To cancel **Continuous Dazzle Mode** (i.e. restore the Home Model to default functioning) simply press the **Start/Stop** button or disconnect the battery/transformer for 20 seconds and then reconnect it, or change the position of the **Function Switch**.

Suggestions

Take the Transporter™ with you on your travels. My wife is a medium and always had trouble sleeping the first night in a hotel room, as she could sense the lingering energies of previous tenets. Now, when we check in, we place the Home Model in the center of the room, for instance, on the bed (the battery cable makes this easy) and put it in continuous mode (see [Continuous Mode](#), above). On return, the room is cleared and she gets a good night's sleep.

I often take the Home Model with me in the car (see [In The Car](#), above).

Use a label maker to label the transformer so you don't get it mixed up with other transformers. The Transformer is that little, black, kinda heavy, cube shaped thing that plugs into the wall—also know as a “battery eliminator”, or wall-wart)

Cautions

The center “purple” light is actually a UV light (Ultraviolet). Though probably harmless, it's wise to keep your eyes at least 3 feet away from it. That's why there's a 5 second delay before the Home Model comes on when it's first powered up—so you have time to move your eyes away.

The thing about UV light is the human eye doesn't react to this frequency. Thus, the iris will not constrict and as a result, the eye can be exposed to the full intensity of this light (especially in a dark room). So, just to be on the safe side, be sure to not look at it unless you are at least 3 feet away. This is true of any UV light—even the ones used to illuminate black-

Instructions for Home Model 600X

light posters and such.

Keep the Home Model away from small children and from pets that might chew on the wiring. Also, keep it away from water or other substances that conduct electricity. There is almost no chance of electrocution, as the voltage conveyed to the Home Model via the power cable is very low, but always error on the side of caution where electricity is involved.

The Home Model is fairly robust and can survive fairly high input voltages and even a reverse in polarity (as long as the reverse voltage isn't too large), but unless advised to do so by an agent of [Joyful Earth Technologies](#) or one of its authorized dealers, any use of a power source other than the supplied transformer or battery cable (with a battery that supplies no greater than 12 volts) will void the warranty.

Warning

A few people reported feeling tired, or "tense" during their first few exposures to the Home Model. This is a reaction to the sudden liberation from the damaging effects of ambient EMFs and the sweetness of having your chakra system in such a pristine state. The Bask cycle (which automatically runs as part of the Clear mode) should ease some or all of these symptoms, but just be aware that if you feel tired, tense, disoriented or even suddenly light and giddy, it is very likely due to the cleansing caused by the Home Model. It will pass, and you will soon adjust to a life free of EMFs.

If the damage to your energy body is extensive, it may take several sessions with the Home Model to fully restore it.

Though rare, because of the possibility of symptoms, please refrain from using your Home Model while driving or operating heavy machinery until you can run the Home Model without symptoms that might impair your motor functions. In all reported cases, the symptoms were temporary and after only a few sessions, usage became asymptomatic.

DISCLAIMER: Tranzzporter™ technology is purely experimental, and is not intended to diagnose or cure any specific condition. We make absolutely no claims of any cure for any disease. Individual results may vary. The Home Model has not been FDA or AMA approved. FDA & AMA regulations require the following disclaimer: "All information in this document and ALL Instruments and items described in this document are provided for educational, research, and informational purposes only and are not intended to be construed as medical advice nor are we intending to practice medicine or lead anyone away from a doctor. We make absolutely no claims of any cure or for any disease."